

# SELECTION SHEET

**RIGHT FRONT Door** 

| Chassis r | Since           |         |  |
|-----------|-----------------|---------|--|
| PEUGEOT   | BOXER II / III  | 04/2010 |  |
| CITROËN   | JUMPER II / III | 04/2010 |  |
|           | DUCATO III      | 06/2011 |  |



## TLS and TLM STEPS 601 - 901 - 1101

### **LEFT FRONT Door**

| Version  | Step                         | <b>Fitting</b>      | kit         | V       | ersion  | Step      | Fitting kit                   |  |
|--|------------------------------|---------------------|-------------|---------|---|-----------|-------------------------------|--|
| 1 / L2 / L3 /I   | _4 601                       | Undevelo            | pped        | L1/I    | _2 / L3 / L4  | 601       | Undevelopped                  |  |
| <b>Comments</b><br>Space available for mounting the step<br>and can be taken up under the chassis. |                              |                     |             | Space   | Comments<br>Space available for mounting the step<br>and can be taken up under the chassis. |           |                               |  |
| LEFT SID   | DE Door<br>EFT HAND<br>Drive | RIGHT HAND<br>Drive | Fitting kit | Version | LEFT HAND<br>Drive  |           | SIDE Door<br>D<br>Fitting kit |  |
| L1   | Drive                        | 601                 | M0003       | L1      | 601   | Drive     | M0003                         |  |
| L2   |                              | 601/901/1101        | M0003       | L2      | 601/901/110   | 1         | M0003                         |  |
| L3 / L4  | 601/901                      | 601/901/1101        | M0003       | L3 / L4 | 601/901/110   | 1 601/901 | M0003                         |  |

#### Comments

The exhaust outlet varies according to left/righthand drive and the length of the vehicle, which makes it impossible to do so.



#### Comments

The exhaust outlet varies according to left/righthand drive and the length of the vehicle, which makes it impossible to do so.

### STEPS POSITION – RIGHT SIDE DOOR

